

Snorkel

www.snorkelusa.com





Platform


Height	126' (38.4 m)
Size96" x 30"	(243.8 cm x 76 cm)
Capacity	500 lbs (227 kg)
Construction	Aluminum


Snorkel TB126J

Machine Dimensions	
Stowed Length 42'9" (13 m)	
Stowed Height 10'4" (3.2 m)	
Wheelbase 12' (3.7 m)	
Width (axles extended). 12' 10" (3.9 m)	
Width (axles retracted) 8' 6" (2.6 m) Weight42,150 lbs (19,119 kg)	

<u>Performance</u>

Power SourceGas or Diesel
Fuel Capacity40 gal (151.4 L)
Hydraulic Capacity90 gal (341 L)
Drive Speed
ElevatedCreep
Stowed3 mph (4.8 km/h)
Gradeability (Theoretical)42%
Horizontal Reach63' (19.2 m)





Standard Features

- Foam filled tires
- Prop. drive, lift, swing, ext. & jib
- Engine anti-restart
- Tie down lugs
- 180 degree hydraulic Platform rotation
- 12 volt emergency operated pwr
- Electric bleed down at chassis And platform
- 4-wheel drive & 4-wheel braking Envelope Management system
- Keyed master switch

- Driveable at full height Tilt alarm
- 125 volt GFCI AC outlet
- Aluminum upper booms
- Hour meter
- High engine temp/low
- oil pressure shut down
- Lifting lugs
- Extendable rear axlesOperator Horn
- Built in chassis jack

Options er • Drive motion alarm

- Platform control box cover
- Flashing light on boom
- Swinging gate
- Sandblast protection kit
- Driving lights Platform work lights
- Cold weather start kit
- Tow kit Airline to Platform
- AC Generator
- Hydraulic Sys. Cold weather Warm-up Kit
- Manufacturing Plant 2009 Roseport Road Elwood, Kansas 66024 800-255-0317 785-989-3000

Australia 26 Redfern Road Wetheril Park NSW 2164 Australia (02) 9725 4000

DANGER: Models described in this brochure are NON-INSULATED and do not provide electrocution protection from contact with or close proximity to energized conductors which is pointed out on decals and placards attached to the machine. Only qualified and trained operators are to be authorized to use and operate a work platform. Aerial work platforms must be elevated only on firm, level surface. Products in this brochure comply with applicable ANSI Standards. This literature is for illustrative purposes only. Consult Operating Maintenance and Parts Manuals for proper procedures. Specifications may vary and are subject to change without notice or obligation.

TB126J-106